Patch materials

Choose the face material before the attachment. AI-edited Cheburashka design illustrations for comparison, not factory proofs or calibrated swatches. Confirm appearance and construction in your sample.



Embroidered
Visible thread and textile texture give a classic stitched appearance. Simplify small lettering and fine gaps; review stitch direction and thread colors in the sample.

2D PVC
Molded PVC with flat-topped raised levels and recessed areas. It can have physical depth even though it is called 2D. Mark the level of each area.

3D PVC
Molded PVC with rounded or sculpted relief. Use front and angled references to explain how the raised surfaces should curve.

For 2D PVC, identify the flat-topped raised levels. For 3D PVC, identify rounded or sculpted areas. Check details, spelling and the border at the intended size.

Patch backing options

Specify the face material and attachment separately. AI-edited Cheburashka design illustrations for comparison, not factory proofs or calibrated swatches. Confirm appearance and construction in your sample.



Velcro
For removable patches on a matching loop panel. Specify hook only or hook plus a separate loop panel, and how the loop panel attaches.

Sew-on
For stitching to the garment. Confirm an embroidered border or a suitable sewing channel on PVC, and check access to stitch the garment.

Iron-on
A heat-activated backing for a compatible textile patch and garment. Confirm fabric suitability and the production-specific application instructions. Do not assume PVC can be ironed.

Temporary adhesive
A peel-and-stick option for temporary use. Confirm material compatibility and surface suitability. Do not assume wash durability or permanent attachment.

PVC patch material is not the same as a PVC backing layer on a textile patch. Ask for the exact construction and care instructions.

Check compatibility before approval

A backing name alone does not establish compatibility with a patch material, garment or surface.

Backing	Embroidered	PVC
Velcro	Specify hook only or include the loop panel.	Confirm how the hook backing is attached.
Sew-on	Confirm the border and stitching access.	Request a suitable sewing channel or edge.
Iron-on	Confirm adhesive and fabric-specific instructions.	Do not assume compatibility or apply heat without approval.
Temporary adhesive	Confirm the surface, duration and removal.	Confirm availability for the intended construction and use.

Swapping patches?
Start with Velcro; check whether a loop panel already exists.

Permanent placement?
Discuss sew-on; check garment access and the correct edge construction.

Heat attachment?
Share the garment care label and follow instructions for the actual patch.

Short-term placement?
Discuss temporary adhesive; confirm the surface and removal expectations.

Sample approval

Check width and height, colors or thread references, lettering, border, relief, back construction and attachment. Where feasible, test the sample on the actual garment. Record the proof version, sample reference and approved changes. No generic heat settings are supplied in this guide.